

Replacing your Spray-Port Faucet Quick Connect Valve



It is very easy to replace your Spray-Away Faucet Quick-Connect. It can be done with just a simple wrench in a couple minutes!



- 1) To begin the replacement of the Quick-Connect, you must **TURN OFF THE WATER** to the RV and release the pressure. This includes turning off the water pump, disconnecting the RV from any water source, and closing the valves. The faucet will be located in a box on the side of the RV or attached to the sink in the water station of the vehicle. To relieve the pressure, plug in the Spray-Away hose to the Quick-Connect and open the faucet by turning both the hot and cold faucets to the “flow” position.
- 2) Unscrew the existing Quick Connect with a 15/16th or 1” deep well socket wrench or any pair of pliers.



- 3) Before screwing on the new Quick-Connect, be sure to seat the supplied black rubber washer into the Quick-Connect. It should be flush with the top of inside of the quick connect to ensure that the Quick-Connect is properly sealed against the male threaded connection of the Spray-Away Faucet.



The washer fits into this part of the Quick Connect and should sit flush against the top to ensure a good seal.

- 4) Screw the new Quick-Connect **WITH THE WASHER IN PLACE** onto the faucet making sure to tighten down to prevent any leaks. “Hand tighten” the Quick Connect to the male part of the Spray-Away Faucet with a wrench or socket.
- 5) Turn on the water and check for any leaks. If there is a leak or no pressure, repeat the above steps to ensure the washer is flush in the Quick-Connect.

You have just replaced your Spray-Away Faucet Quick Connect!

D&W assumes no responsibility for any injury or property damage that may be incurred in the replacement of this part.